



## Take 2™ Message-On-Hold Adapter

*2-Line Message-On-Hold Adapter*

The **Take 2** is a state-of-the-art message-on-hold adapter capable of allowing the user to place up to two callers on-hold. An external audio source can be connected to the adapter to keep callers entertained and informed of your products or services. This system is specifically designed for the SOHO (Small Office Home Office) environment where up to two lines on a single phone are supported.



Placing a caller on hold is simple, just press the appropriate line button on the adapter and the caller is instantly placed on hold. The handset then can be placed back on the cradle or another line can be accessed. While the caller is holding an audio source such as a digital message repeater can be fed into the adapter allowing the caller on hold to be entertained or informed about your products or services. While the caller is on hold a blue LED light above the line number on the adapter will glow.

The Take 2 comes with all the necessary audio and telephone cables to allow the system to be easily connected. The modern design and added functionality make this a great addition to any two-line office phone.

The Take 2 adapter features include:

- RCA input for MOH device
- Modular connections
- Place up to 2 callers on-hold
- Large easy-to-push buttons
- Blue LED status indicators
- Durable high-impact plastic case
- Custom emblem area
- All cables included
- Exceptional dealer support
- Designed and manufactured in the USA
- 5-year parts and labor warranty


Each Take 2 adapter is built to exacting quality standards using state-of-the-art assembly equipment for outstanding reliability and years of dependable service.



# Instructions

## Technical

1. Unplug the line connection from the rear of the telephone and connect this to the **TELCO** plug on the adapter.
2. Connect included RJ-11 cord from phone line connection to the **PHONE** plug of the adapter.
3. Connect included RCA cord from the adapters **AUDIO IN** to an audio source. Do not connect to an amplifier or damage to the adapter will occur.
4. Connect the attached **POWER SUPPLY** to a powered wall outlet.



### Installation Note:

If this is a two-line installation and both lines ARE NOT coming into the phone on the same wire then an adapter must be used. A Radio Shack 279-357 can be used to take both lines and put them onto one wire. Then a Radio Shack 279-358 phone line coupler can be used to convert this to a connector so a RJ-11 line wire can be connected to the line input of the adapter.

### Audio Resource Center

Toll Free: 1-888-468-5457

Fax: 1-727-726-4659

Email: [csmith@audioresourcecenter.com](mailto:csmith@audioresourcecenter.com)

Web: [www.audioresourcecenter.com](http://www.audioresourcecenter.com)